

PRICE CHANGER

hITECH
ELECTRONIC DISPLAYS

HOW TO CHANGE PRICES

Turn displays on and allow self-test to complete and then proceed with following:

Step 1 - Press SET

'Top Right digit begins to blink'

Step 2 - Enter 6 digit PASSWORD

(default password 123456).

Enter 1 digit at a time as prompted

'If password is successful than the 1st (left) digit will begin to blink'


Step 3 - Change first blinking digit by pressing desired number on remote

Step 4 - Continue to change all digits until price is correct

Step 5 - Press ENTER to move to next display for editing. Repeat steps 3 thru 5 until complete.

Step 6 - Press SET when all prices have been Changed.

NOTE: If no response from user within 30 seconds during editing stage the display being setup will go back to normal display mode.



REMOTE CONTROLS

Numbers 0 – 9

Used to change figures or enter password

SET

Used to enter or exit setting mode.
Saves pricing

ENTER

Used to choose display to change

P A S S W O R D

800-723-9402
727-531-4800 Fax: 727-524-6655
sales@hitechled.com

hITECH
ELECTRONIC DISPLAYS
www.hitechled.com

SINCE 1984

PRICE CHANGER

hITECH
ELECTRONIC DISPLAYS

HOW TO CHANGE PRICES

Turn displays on and allow self-test to complete and then proceed with following:

Step 1 - Press SET

'Top Right digit begins to blink'

Step 2 - Enter 6 digit PASSWORD

(default password 123456).

Enter 1 digit at a time as prompted

'If password is successful than the 1st (left) digit will begin to blink'


Step 3 - Change first blinking digit by pressing desired number on remote

Step 4 - Continue to change all digits until price is correct

Step 5 - Press ENTER to move to next display for editing. Repeat steps 3 thru 5 until complete.

Step 6 - Press SET when all prices have been Changed.

NOTE: If no response from user within 30 seconds during editing stage the display being setup will go back to normal display mode.



REMOTE CONTROLS

Numbers 0 – 9

Used to change figures or enter password

SET

Used to enter or exit setting mode.
Saves pricing

ENTER

Used to choose display to change

P A S S W O R D

800-723-9402
727-531-4800 Fax: 727-524-6655
sales@hitechled.com

hITECH
ELECTRONIC DISPLAYS
www.hitechled.com

SINCE 1984



WIRELESS RECEIVER

REGULAR
13.48

PLUS
15.48

SUPER
16.48

DIESEL
13.48

← MASTER DISPLAY

← DISPLAY SLAVE 1

← DISPLAY SLAVE 2

← DISPLAY SLAVE 3



800-723-9402
727-531-4800 Fax: 727-524-6655
sales@hitechled.com



WIRELESS RECEIVER

REGULAR
13.48

PLUS
15.48

SUPER
16.48

DIESEL
13.48

← MASTER DISPLAY

← DISPLAY SLAVE 1

← DISPLAY SLAVE 2

← DISPLAY SLAVE 3



800-723-9402
727-531-4800 Fax: 727-524-6655
sales@hitechled.com

